

# LITHIUM LTD

## MODULE CHART

MOD POSITION	DRAW STOP	DRAW LENGTH	ATA	BRACE
1	0	26.5"	33 1/16"	6 1/16"
2	0.5	27"	33 1/16"	6 1/16"
3	1.5	27.5"	33 1/16"	6 1/16"
4	3	28"	33 1/16"	6 1/16"
5	4	28.5"	33 1/16"	6 1/16"
6	5.5	29"	33 1/16"	6 1/16"
7	6.5	29.5"	33 1/16"	6 1/16"

### **\*Adjust Draw Stops Correctly**

Ensure that the draw stop is set correctly, if they are set too far back, the misalignment may cause a lockup during draw.

### **\*Module Alignment**

Ensure that both cam modules are set to the same corresponding mark.

### **\*Alignment with Draw Stop**

Remember to use the leading edge to align for your desired draw stop position.

### **\*WARNING**

Never draw your bow without draw stop installed and properly adjusted.

